USB 2.0 Video Capture for Windows

(Model no: VCAP800)

User Manual

ClimaxDigital UK

Email: <u>support@climaxdigital.co.uk</u> Website: <u>http://www.climaxdigital.co.uk</u> Support: <u>http://www.climaxdigital.co.uk/support</u>

1. Instroduction

VCAP800 USB 2.0 video capture enables you to convert video+audio from your old VHS, V8, Hi8, camcorder, video recorder, DVD player or Satellite TV receiver to DVD/VCD. Using the software VHS2DVD, you can edit your newly captured video file, add titles, music etc before burning it to DVD/VCD. With unique "push to start, push to stop" button, you can easily capture the video clips you'd like to save. Simply press the button on VCAP800 to start recording, then press it again to stop recording. The captured video clips will be automatically saved on your hard drive.

Features

- Easy to use, push to start push to stop capture button
- USB 2.0 PnP Interface
- Real-Time MPEG 4/2/1 encoding
- Burn edited files onto DVD, VCD, SVCD...
- Capture video source from VHS, V8, Hi8...
- Burn your own DVD/VCD
- USB audio support, one USB cable to your PC, particularly useful for notebook without Line in port
- Support composite AV (yellow, red, white) and S-video input.
- User friendly interface.

Specification

- USB 2.0 PnP Interface, USB video/audio transfer
- Automatic NTSC/PAL detection
- Push to Start/Push to Stop button
- Capture the Video directly into MPEG 1/2/4 Format
- Capture Video Source from VHS, V8, Hi8 etc.
- Support Still Image Capture in JPEG or BMP format
- Video resolution-NTSC 720*480@30 FPS
 - -PAL 720*576@25 FPS
- External video input: Composite and S-Video
- MPEG Encoder/ *MPEG Editor /*Burn DVD

Applications:

- Internet video meeting
- Video phone
- Video-audio animation transcribing and editing
- Make VCD, DVD and Website
- Enterprise bulletin and advertisement

System requirement

- Intel Pentium4 2.4G CPU or above.
- 512MB RAM or above
- One free high speed USB2.0 port
- VGA card supports DirectX9.0
- CD-ROM (for installation)
- At least 1GB free HDD. 300MB HD space for driver and application. It needs 600MB to 3GB for one hour's recording
- Windows XP, Vista or Windows 7

What's in the box

- VCAP800 USB 2.0 Video Capture
- AV cable 3-3
- Software/driver CD

2. Quick Start Guide

Step 1: Insert the CD-ROM to install the drivers and application software.

Step 2: Connect ClimaxDigital USB 2.0 Video Capture to your analog video source and then to a free USB 2.0 port on your computer.

Step 3: Launch VHS2DVD software to capture video and audio onto your computer.

Step 4: Edit the captured video files with VHS2DVD software.

Step 5: Transfer the captured video to your iPod, PSP or upload the captured videos directly to YouTube. You can also burn the edited video to DVD as well.

3. Connection Guide

3.1 VCAP800 USB 2.0 Video Capture Connection Diagram



Important

- Please make sure you connect the **VCAP800** USB video capture to the OUTPUT port of your video source device. USB video capture does NOT workwith the video input port on your video source device.
- If the video OUTPUT port on your video source is svideo female, then you need to get S-VHS (S-Video) extension lead (male to male). If the video OUTPUT port on your video source device is composite AV (Yellow, red, white) female, then you need to use the included RGB to RGB lead (male to male). If your video port is SCART, then you will need SCART to RGB convertor or cable.
- Please be advised that you ONLY need one of the following connections 1)Composite AV (yellow, red, white)+audio 2)Svideo +audio

Please do NOT connect AV and Svideo at the same time. You only need one of them.

3.2 Composite-Video

Connect the yellow composite video input to the corresponding output of your video source. Also connect the RCA audio inputs with the audio outputs of the source device. You need to use the included composite AV cable.



3.3 S-Video (S-VHS)

Connect the S-Video (S-VHS) input to the corresponding output of your video source. Also connect the RCA audio inputs with the audio outputs of the source. You need to use S-Video Cable (not included) and the included Red/White audio cable.



3.4 SCART and Composite AV

Connect the SCART to composite AV adaptor to the SCART output of your video source. And then connect the USB 2.0 video capture to the SCART to composite AV adaptor via the included Composite AV cable (Yellow, Red, White cable)

Most of the SCART to RCA leads on the market works by submitting a signal from RCA to SCART. It is not good for the USB video capture. You need to make sure that the lead is "SCART OUT" i.e. signal goes from SCART to RCA. If you have a switchable SCART to 3 X phono or switchable SCART to phono adaptor, please make sure the cable or the adaptor is switched to output composite AV signal.



3.5 SCART and S-Video

Connect the SCART to S-Video adaptor to the SCART output of your video source. And then connect the USB 2.0 video capture to the SCART to S-Video adaptor via S-Video cable (not included)

IMPORTANT!

Most of the SCART to S-Video leads on the market works by submitting a signal from S-Video to SCART. It is not good for the USB video capture. You need to make sure that the lead is "SCART OUT" i.e. signal goes from SCART to S-Video. If you have a switchable SCART to S-Video or switchable SCART to S-Video adaptor, please make sure the

cable or the adaptor is switched to output S-Video signal.



3.6 How to connect to game consoles? (Wii/PS3/Xbox 360)

In addition to the cables/adaptors mentioned above, you also need

- 2 X Composite AV leads
- 3 X Female to female phono splitters (used for each phono lead that comes from the game console)



You need to take the steps below to get it connected

- 1) Connect the Y splitters to the lead from your gaming console
- 2) Connect 1st composite AV lead (Yellow, Red, White) from the splitters to the TV
- 3) Connect 2nd composite AV lead (Yellow, Red, White) from the splitters to the USB 2.0 video capture
- Set your game consoles to output STANARD composite AV signal since this USB 2.0 video capture does NOT support HD.

4. Driver and Application Installation

Step1: (for Windows XP)OS will remind a new hardware-- "New Hardware Device" was found. Please choose "Cancel". If you user Windows Vista/Windows 7, windows will try to find and install the driver.



Step2: When CD is inserted, OS will guide you to the setup automatically. Click "**Driver Install**" or run **Windows\Drive\Setup.exe**,



Step3: Click "next" to continue installation



Step4:Click "Install" to continue installation driver

Drv - InstallShield Wizard	
Ready to Install the Program The wizard is ready to begin installation.	No.
Click Install to begin the installation.	
If you want to review or change any of your the wizard.	installation settings, click Back. Click Cancel to exit
InstallShield	< <u>B</u> ack Install Cancel

Step5: Click "Finish" to completely install the Driver Software

Drv - InstallShield Wizard	
	Drv Setup Setup has completed installing Drv.
	Click Finish to exit Drv setup.
	< Back Finish Cancel

Install Honestech VHS to DVD Editing Software.

Step 14:Click "Install VHS to DVD" or run "Windows\VHS2DVD\Setup.exe" to install edit software, Choose your favor ate language .

honestech VHS to DVD 3.0 SE - InstallShield Wizard
Choose Setup Language Select the language for the installation from the choices below.
English French (Canadian) French (Standard) German Japanese Korean Portuguese (Brazilian) Spanish
InstallShield

Step 15: Click "next" to continue installation

honestech VHS to DVD 3.0 SE Setup	
honestech VHS to DVD 3.0 SE 3	Welcome to the InstallShield Wizard for honestech VHS to DVD 3.0 SE The InstallShield Wizard will install honestech VHS to DVD 3.0 SE on your computer. To continue, click Next.
	< Back Next > Cancel

Step 16: Click "I accept the terms of license agreement", then click "next" to continue installation.

License Agreement		
Please read the following license agreer	ment carefully.	honestech
(c) Honest Technology. All rights reserving honestech products referred to herein a trademarks of honestech. All other trade Information contained herein is subject	ved. honestech, the honester are either the trademarks or the emarks are property of their re to change without notice.	ch logo, and the e registered spective owners.
Software License Agreement, HONEST SOFTWARE TO YOU ONLY ON THE TERMS CONTAINED IN THIS LICENS between you (either an individual end-u software, you are agreeing to be bound you do not agree to the terms of this Ag remove the software together with all co	FECH IS WILLING TO LICEN CONDITION THAT YOU ACC SE AGREEMENT. This is a ley iser or an entity) and honested by the terms and conditions of greement do not install or use to opies and return the software	SE THE SEPT ALL OF THE gal agreement sh. By using the of the Agreement. If he software. Promptly package and other
I accept the terms of the license agrigation of the license agrigat	eement	<u>Print</u>
	ise agreement	
nstallShield —	< <u>B</u> ack N	ext > Cancel
ep17: Software will be installed in	< <u>Back</u> the C disk.	ext > Cancel
ep17: Software will be installed in onestech VHS to DVD 3.0 SE Setup	the C disk.	ext > Cancel

Select fo	older where setup will install files.
	Install honestech VHS to DVD 3.0 SE to: C:\Program Files\honestech VHS to DVD 3.0 SE
InstallShield -	< <u>B</u> ack Next > Cancel

Step18: Select Program Folder

honestech VHS to DVD 3.0 SE Setup	
Select Program Folder	15th
Please select a program folder.	honestech
Setup will add program icons to the Progra name, or select one from the existing folde	am Folder listed below. You may type a new folder ers list. Click Next to continue
Program Folder:	
honestech VHS to DVD 3.0 SE	
Existing Folders:	
Accessories	
Administrative Tools Games	
Maintenance	
Porsche Turbo 2010 PCTV	
Startup	
Tablet PC	
InstallShield	
ten19: Click" install" to continue i	installation

honestech VHS to DVD 3.0 SE Setup	×
Ready to Install the Program The wizard is ready to begin installation.	ht.
Click Install to begin the installation.	200
If you want to review or change any of your installation settings, clic the wizard.	k Back. Click Cancel to exit
InstallShield	Install Cancel

Step20: Click" Finish", then the software installation is finished.



Step20: Icon on your desktop



Step18: When all finished, please check on open the control panel, select "**System**", select "**system**", select "**Device Manager**", you can see four new device drivers installed.

IGrabber Device IGrabber Audio Device

🚇 Device Manager	
Eile <u>A</u> ction <u>V</u> iew <u>H</u> elp	
🗆 🕮 ्	~
E Disk drives	
Mice and other pointing devices	
The Monitors	
🛨 🎟 Network adapters	
🗄 🎐 Ports (COM & LPT)	
🕀 🛲 Processors	
🖃 🧐 Sound, video and game controllers	
Audio Codecs	
iGrabber Device	
Legacy Audio Drivers	
Legacy Video Capture Devices	
Media Control Devices	
	~

Step19: VHS 2 DVD Capture Application

How to use VHS to DVD 3.0, you can get online help by pressing the question mark "?"



20. Setting within VHS2DVD

1)Video device: IGrabber device
2)Audio device: IGrabber device or USB EMP audio device
3)Format: you can choose DVD or long DVD or other formats
4)Video Type: PAL
5)Quality: Best
6)Split size: please choose the one that match the DVD disck you use
7)connection setting:
VHS2DVD--->options-->video device setting-->input source-->choose
"composite" if you use yellow, red, white cable. Choose Svideo if you use Svideo cable.
8)The Video source must be set to either 'Composite' or 'Svideo' depending on which connector you are using (the yellow phono connector is Composite and the black mini-DIN connector is s-video)

5. Frequently Asked Questions

Question: I am unable to connect the USB 2.0 Video Capture to my VCR / camcorder / DVD player – what can I do?

Answer: When you buy a VCR, camcorder or DVD player you are usually supplied with an 'RGB lead'. This lead has three yellow, red and white connectors at each end, or alternatively it may have these connectors at one end and a Scart jack at the other end.

Question: If you have a 'mono' camcorder, when you connect it up you may get no audio whatsoever. Must I have a stereo camcorder?

Answer: The USB 2.0 Video Capture can work with a 'mono' camcorder.

Question: Can you see what you are recording?

Answer: yes, A small window is found at the top of the screen to show what you are recording.

Question: If my Video is e.g. 180mins long, will it take this long to transfer via the USB 2.0 Video Capture? Answer: Yes

Question: Can the USB 2.0 Video Capture be used to record videos from other devices such as a Sky box or straight from a television, or anything along those lines?

Answer: Yes it can. As long as the device you wish to record from has the relevant outputs required (Red, White and Yellow phono video lead). These must be outputs and not inputs otherwise it will not work. Please check the device's manual first to see whether your device has the outputs needed.

Question: Can I copy original movies onto my computer using the USB 2.0 Video Capture?

Answer: No, this is illegal. It is piracy to copy a film and then sell or lend it to another person without permission to do so.

Question: Will the videos I record onto my computer take up much space?

Answer: Yes they will. Video files are large files. You can choose the quality of the video to save space on your computer. The lower quality for the smaller file.

Question: How long will it take to record?

Answer: This is a real time capture device therefore it will take 3 hours to record a 3 hour tape.

Question: How many hours of video tape will produce 1GB of digital data.

Answer: The space depends on which format and which size you choose. For example: in AVI format there is no compression of data, and therefore it produces about 1GB for 10 minutes recording. However it only uses around 200MB if using MPEG format, and only about 30MB if using WMV format.

Question: Is the USB 2.0 Video Capture compatible with the old style video 8mm camcorders?

Answer: Yes it is. You will have to by a connection lead. You may require an RGB lead.

Question: How to fix the audio driver problem for Windows 7?

How to fix the audio driver error (code 10) for Windows 7? How to fix the problem if there is a yellow mark beside the audio driver?

Answer: please the steps below to get it fixed.

- Plug in USB 2.0 video capture
- In Device Manager under `Sound, video and game controllers" does it state "USB EMP Audio Driver"? If so, it needs to be changed to "USB Audio Device"
- Right click `USB EMP Audio Driver' then `Update Driver Software'
- Click on `Browse my computer for driver software'
- Then 'let me pick from a list'
- Tick `show compatible hardware'.
 This should give you two driver options, Window's own `USB Audio Device' and the `USB EMP Audio Device' driver.
- Select the `USB Audio Device'.
- Reboot the pc.

Thank you for your purchase. We appreciate your business. Please contact us should you have any questions or comments

ClimaxDigital UK Email: <u>support@climaxdigital.co.uk</u> Website: <u>http://www.climaxdigital.co.uk</u>